



HEIRLOOM STYLE DOLL CRADLE WITH BEDDING

Assembly and Use Instructions. Adult Assembly Required. Read all instructions before use.

This manual is part of the product and must be saved for future reference.



MODEL NUMBER*:

01835

VERSION CODE*:

6.0/0420/TG

** These numbers are needed if replacement parts are requested*

Find us on  •  **YouTube** • 

Assembly Videos available on YouTube

FOR REPLACEMENT PARTS:
<http://www.badgerbasket.com/parts>

Badger Basket®, PO Box 227, Edgar, WI 54426-0227 USA • **Web:** www.badgerbasket.com
U.S. Based Customer Service Toll-Free (Mon-Thurs 7:00 AM-4:00 PM CST): 1-800-236-1310
Phone: 715-352-2311 • **Fax:** 715-352-3163



BEFORE YOU BEGIN ASSEMBLY:

Check all parts and hardware. If anything is missing or not satisfactory, please DO NOT call the store or return the product to them. Please go online to:

<http://www.badgerbasket.com/parts>

Most problems are resolved without you needing to leave home.

If emailing or calling us, please have this instruction manual, your product model number, and your Version Code ready.

Your Model Number is: 01835

Your Version Code is: 6.0/0420/TG

CARE INSTRUCTIONS:

Wipe clean with a damp cloth and mild soap as needed. The fabric parts are made with poly/cotton fabric. The stuffing is polyfill. For longevity of the product, we recommend spot cleaning or gently hand washing as needed; however you can machine wash the fabric parts in cold water, gentle cycle and air dry or tumble dry low if desired.



WARNING - CAUTION




ADULT ASSEMBLY REQUIRED
DUE TO THE PRESENCE OF SMALL PARTS AND SHARP POINTS DURING ASSEMBLY, KEEP OUT OF REACH OF CHILDREN UNTIL ASSEMBLY IS COMPLETE.


READ ALL INSTRUCTIONS before use of this product. Use only the parts and hardware provided by Badger Basket. Keep instructions for future use. Do not use the product if it is damaged or broken. Periodically inspect the product and retighten hardware if needed. **This item is a toy for dolls only.** It is never to be used for real children or pets. **For children ages three (3) years and older. Never attempt to sit or stand on the toy.**
No product is a substitute for adult supervision.
Always supervise your child during play.




ASSEMBLY TIPS! Review the entire manual before beginning. Leave hardware slightly loose during assembly and then go back and tighten fully at the end. If using a power screwdriver, keep torque setting low and go slow to prevent damage to the product.




END
A×2




SIDE
B×2




BOTTOM
C




STAND
D



RAILS
E




FABRIC MATTRESS
F




FABRIC BLANKET
G



SCREW
Ø 5×35mm
H×14




PHILLIPS SCREWDRIVER
TOOL
(NOT INCLUDED)



(1)




H×4



(2)




H×4



(3)



H×3



H×3

