



JUST LIKE MOMMY 3-IN-1 DOLL PRAM, CARRIER, STROLLER

Assembly and Use Instructions. Adult assembly Required.
Read all instructions before use. This manual is part of the product and must be saved for future reference.

MODEL NUMBERS*:

00561 - Pink Rosebud
00562 - Pink Gingham
00563 - Pink/White Polka Dot
09922 - Navy/White
99564 - Gray/White Polka Dot

VERSION CODE*:

6.0/0816/HF

** Model and Version numbers are needed
if replacement parts are requested*



**If you need product
parts, see below or Page 2!**

FOR REPLACEMENT PARTS:

Go to our web site: <http://www.badgerbasket.com/parts>
Or scan QR code at right with your smartphone





BEFORE YOU BEGIN ASSEMBLY:

Check all parts. If anything is missing or not satisfactory, please DO NOT call the store or return the product to them. Please go online to:

<http://www.badgerbasket.com/parts>

Most problems are resolved without you needing to leave home.

When contacting us, please have this instruction manual, your product model number, and your Version Code ready.

Your Model Number is: SEE COVER PAGE

Your Version Code is: 6.0/0816/HF



WARNING

ADULT ASSEMBLY REQUIRED

DUE TO THE PRESENCE OF SMALL PARTS AND SHARP POINTS DURING ASSEMBLY, KEEP OUT OF REACH OF CHILDREN UNTIL ASSEMBLY IS COMPLETE.




WARNING - CAUTION

READ ALL INSTRUCTIONS before use of this product. Use only the parts and hardware provided by Badger Basket. Keep instructions for future use. Do not use the product if it is damaged or broken. Periodically inspect the product to ensure all parts remain tight. **This item is a toy for dolls only. It is never to be used for real infants or pets. No product is a substitute for adult supervision. Always supervise your child during play.** For children ages three (3) years and older. Never sit on or stand on the toy.


PARTS AND HARDWARE INCLUDED:

- (A) 1 x Stroller/Frame
- (B) 2 x Metal Rods
- (C) 4 x Wheel Spacers
- (D) 4 x Wheels
- (E) 1 x Carrier/Pram Unit with pad, boot, and hood

ASSEMBLY:





STEP 1: Insert the **TWO METAL AXLE RODS (B)** through the holes in the **STROLLER FRAME (A)**.





STEP 2: Slide **ONE WHEEL SPACER (C)** onto each of the **FOUR** ends of the **METAL AXLE RODS (B)**. Attach the **FOUR WHEELS (D)** to the ends of the **AXLE RODS (B)**. Push inward on the metal bracket at the center of the wheel to open it, slip the wheel onto the end of the rod, and release the bracket. If you tug on the wheels they should not come off.


STEP 3: Unfold the stroller. Slide the frame locks down until they cover the ends of the tubes. **Reverse this step when you want to fold the stroller.** The passive safety locks are designed to stop the stroller from fully collapsing if the frame locks are unexpectedly released.



STEP 4 (DIAGRAMS ON NEXT PAGE): Remove the fabric boot and fabric pad from the **CARRIER/PRAM UNIT (E)**. Unfold the metal frame support bars inside and snap them under the plastic clips that are attached to the bottom board of the carrier (PART E). Prop open the hood by snapping the support bars together on both sides of the hood.



STEP 5: To use as a PRAM, position the STROLLER seat so that it is flat/horizontal. You will hear the adjustment dials click as the seat position is adjusted. Set the carrier on top of the stroller seat (facing forward or backward). Snap the clips on the STROLLER FRAME over the metal side bars on the CARRIER. Be sure the clips are snapped properly to hold the carrier tight to the frame.



USE AND CARE INSTRUCTIONS:
Wipe metal and plastic parts clean with a damp cloth and mild soap as needed.
Spot clean fabric with mild detergent and cold water as needed.

