

STARLIGHTS CANOPY METAL DOLL BED WITH BEDDING - PINK

Assembly Instructions. Adult Assembly Required.
Read all instructions before use.

This manual is part of the product and must be kept for future reference.



MODEL NUMBER*: 60001

VERSION CODE*: 1.0/0519/TG


* Model and Version numbers are needed if replacement parts are requested

Find us on **f** • **VouTube**

FOR REPLACEMENT PARTS:

http://www.badgerbasket.com/parts

Badger Basket®, PO Box 227, Edgar, WI 54426-0227 USA • Web: www.badgerbasket.com U.S. Based Customer Service Toll-Free (Mon-Thurs 7:00 AM-4:00 PM CST): 1-800-236-1310 Phone: 715-352-2311 • Fax: 715-352-3163



BEFORE YOU BEGIN ASSEMBLY:

Check all parts. If anything is missing or not satisfactory, please DO NOT call the store or return the product to them. Please go online to: http://www.badgerbasket.com/parts

Most problems are resolved without you needing to leave home. When emailing or calling us, please have this instruction manual, your product model number, and your Version Code ready.

Your Model Number is: 60001 Your Version Code is: 1.0/0519/TG

CARE INSTRUCTIONS:

All cleaning must be done carefully to prevent water from contacting the lights, electronics, and batteries. Frame and attached fabrics can be spot and wiped clean with a damp cloth and mild soap and dry thoroughly. Removable fabric pieces can be hand washed in cold water and mild detergent and allow to air dry.



WARNING

ADULT ASSEMBLY REQUIRED. DUE TO THE PRESENCE OF SMALL PARTS AND SHARP POINTS DURING ASSEMBLY, KEEP OUT OF REACH OF CHILDREN UNTIL ASSEMBLY IS COMPLETE.





WARNING - CAUTION

READ ALL INSTRUCTIONS before use of this product. Use only the parts provided by Badger Basket®. Keep instructions for future use.

Do not use the product if it is damaged or broken. Periodically inspect the product to ensure all parts remain tight. This item is a toy for dolls only. It is never to be used for real infants or pets. No product is a substitute for adult supervision. Always supervise your child during play.

For children ages three (3) years and older. Never sit on or stand on the toy.


BATTERY SAFETY INFORMATION:


- This toy requires two (2) "AA" size batteries. Batteries are NOT included.
- Batteries must be replaced by an adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before charging.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old batteries and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Be sure to insert batteries with the correct polarities.
- Exhausted batteries are to be removed from the product promptly.
- The supply terminals are not to be short circuited.
- Dispose of batteries safely.
- Remove batteries from the product if it will be unused for an extended period of time.
- Toy is intended for indoor, dry location use only.





ASSEMBLY TIPS! Review the entire manual before beginning. Leave hardware slightly loose during assembly and then go back and tighten fully at the end. If using a power screwdriver, keep torque setting low and go slow to prevent damage to the product.





Slide the top pocket of the FABRIC CANOPY WITH LIGHTS (F) onto the each arm of the METAL CANOPY HOOP (G).

